## **COMPREHENSIVE SERVICES**

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

# SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs. We Sell For Cash We Get Credit We Receive a Trade-In Deal

**OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP** 

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.

APEX WAVES

**Bridging the gap** between the manufacturer and your legacy test system.

1-800-915-6216
www.apexwaves.com
sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote CLICK HERE NI-9221



## **Board Assembly Part Number(s)**

| Part Number | Description  |
|-------------|--|
| 194932A-01L | 8-CHANNEL ANALOG INPUT SCREW TERMINAL                  |
| 194934A-01L | 8-CHANNEL ANALOG INPUT w/25 PIN DSUB                   |
| 194932A-06L | 8-CHANNEL ANALOG INPUT SPRING TERMINAL                 |
| 194934A-03L | 8-CHANNEL ANALOG INPUT CONFORMAL COATING w/25 PIN DSUB |

#### Manufacturer: National Instruments

#### Volatile Memory

| <b>G</b> . | User Accessible/                                    | Battery  |  |  |
|------------|---|--|--|--|
| Size       | System Accessible <sup>1</sup>                      | Backup?  | Purpose  | Method of Clearing <sup>2</sup>  |
| 12 bits    | Yes/Yes   | No   | Stores last digitized value  | Cycle power  |
| 1 byte     | No/No   | No   | Stores selected channel  | Cycle power  |
| 1 byte     | No/Yes  | No   | Stores Module Configuration  | Cycle power  |
| Memory     |   |  |  |  |
| •          | User Accessible/                                    | Battery  |  |  |
| Size       | System Accessible                                   | Backup?  | Purpose  | Method of Clearing   |
| 1 KB       | No/Yes  | No   | Module ID and calibration <sup>3</sup>   | None available to user   |
| 8-bit      | No/No   | No   |  | None available to user   |
|            |   |  | I I I I I I I I I I I I I I I I I I I  |  |
| ge         |   |  |  |  |
| -          | User Accessible/                                    | Battery  |  |  |
| Size       | System Accessible                                   | Backup?  | Purpose  | Method of Clearing   |
|            | 1 byte<br>1 byte<br>Memory<br>Size<br>1 KB<br>8-bit | Size System Accessible <sup>1</sup> 12 bits Yes/Yes   1 byte No/No   1 byte No/Yes   Memory User Accessible/   Size System Accessible   1 KB No/Yes   8-bit No/Yes   ge User Accessible/ | SizeSystem Accessible1Backup?12 bitsYes/YesNo1 byteNo/NoNo1 byteNo/YesNoMemoryUser Accessible/BatterySizeSystem AccessibleBackup?1 KBNo/YesNo8-bitNo/NoNogeUser Accessible/Battery | Size System Accessible <sup>1</sup> Backup? Purpose   12 bits Yes/Yes No Stores last digitized value   1 byte No/No No Stores selected channel   1 byte No/Yes No Stores Module Configuration   Memory User Accessible/ Battery   Size System Accessible Backup? Purpose   1 KB No/Yes No Module ID and calibration <sup>3</sup> 8-bit No/No No Isolation common mode compensation |

NONE

1

## **Clearing Notes:**

**EEPROM:** User accessibility of the calibration EEPROM is exposed through an external calibration Applications Programming Interface (API) in LabVIEW. To declassify this memory, complete the steps listed in KB <u>4GHLANQE</u> (Clearing the User-Accessible EEPROM on an NI-DAQmx Supported Device).

Items are designated **No** for the following reason(s):

a) Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed.

b) Hardware-modifying software tools are not distributed to customers for any personal access or customization, also known as non-normal use.

<sup>&</sup>lt;sup>2</sup> The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to clear the memory are not distributed by National Instruments to customers for normal use.

<sup>&</sup>lt;sup>3</sup> Calibration constants that are stored in device EEPROMs include information for the device's full operating range. Calibration constants do not maintain any unique data for specific configurations at which the device is used unless otherwise specified.



## **Terms and Definitions**

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

**System Accessible** Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

**Cycle Power** The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

**Non-Volatile** Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.