

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

PXIe-5665

PXIe-5665

3.6 GHz or 14 GHz Vector Signal Analyzer



Note Before you begin, install and configure your chassis and controller.

This document explains how to install, configure, and test the PXIe-5665. The PXIe-5665 is a 3.6 GHz or 14 GHz modular RF vector signal analyzer (VSA). The PXIe-5665 ships with the NI-RFSA instrument driver, which you can use to program the device. You can also use NI-RFmx, available at ni.com/downloads, to program the device.

The PXIe-5665 comprises the following devices:

- PXIe-5603 or PXIe-5605 RF downconverter
- PXIe-5622 intermediate frequency (IF) digitizer
- PXIe-5653 synthesizer/local oscillator (LO) source module

When not otherwise specified, the instructions for the PXIe-5665 in this document refer to both the PXIe-5665 3.6 GHz VSA and the PXIe-5665 14 GHz VSA.



Caution The protection provided by this product may be impaired if it is used in a manner not described in this document.



Hot Surface If the PXIe-5665 has been in use, it may exceed safe handling temperatures and cause burns. Allow the PXIe-5665 to cool before removing it from the chassis.

Contents

| | |
|---|----|
| Electromagnetic Compatibility Guidelines..... | 2 |
| Verifying the System Requirements..... | 2 |
| Unpacking the Kit..... | 2 |
| Verifying the Kit Contents..... | 4 |
| Preparing the Environment..... | 5 |
| Choosing and Installing the Software..... | 6 |
| Software Options..... | 6 |
| Installing the Software..... | 6 |
| Installing the PXIe-5665..... | 7 |
| Interconnecting the PXIe-5665 Modules..... | 8 |
| Configuring the PXIe-5665 in MAX..... | 22 |
| Self-Calibration..... | 23 |
| Performing a Device Self-Calibration Using the NI-RFSA SFP..... | 23 |

| | |
|---|----|
| Locating the Software and Examples..... | 24 |
| Software Locations..... | 24 |
| Programming Examples Locations..... | 26 |
| Troubleshooting..... | 27 |
| Installation..... | 27 |
| Configuration..... | 28 |
| Measurements..... | 29 |
| Where to Go Next..... | 30 |
| Worldwide Support and Services..... | 30 |

Electromagnetic Compatibility Guidelines

This product was tested and complies with the regulatory requirements and limits for electromagnetic compatibility (EMC) stated in the product specifications. These requirements and limits provide reasonable protection against harmful interference when the product is operated in the intended operational electromagnetic environment.

This product is intended for use in industrial locations. However, harmful interference may occur in some installations, when the product is connected to a peripheral device or test object, or if the product is used in residential or commercial areas. To minimize interference with radio and television reception and prevent unacceptable performance degradation, install and use this product in strict accordance with the instructions in the product documentation.

Furthermore, any changes or modifications to the product not expressly approved by National Instruments could void your authority to operate it under your local regulatory rules.



Caution To ensure the specified EMC performance, operate this product only with shielded cables and accessories.



Caution To ensure the specified EMC performance, operate this product only with cables less than 3 meters in length.

Verifying the System Requirements

To use the PXIe-5665, your system must meet certain requirements. For more information about minimum system requirements, recommended system, and supported application development environments (ADEs), refer to the readme, which is available on the software media or online at ni.com/updates.

Unpacking the Kit



Caution To prevent electrostatic discharge (ESD) from damaging the device, ground yourself using a grounding strap or by holding a grounded object, such as your computer chassis.

1. Touch the antistatic package to a metal part of the computer chassis.

2. Remove the device from the package and inspect the device for loose components or any other sign of damage.



Caution Never touch the exposed pins of connectors.




Note Do not install a device if it appears damaged in any way.

3. Unpack any other items and documentation from the kit.

Store the device in the antistatic package when the device is not in use.

Verifying the Kit Contents

Figure 1. PXle-5665 Kit Contents



-
- | | |
|---|--|
| 1. PXle-5622 IF Digitizer Module | 8. Screwdriver, Part Number 772006-01 |
| 2. PXle-5603 or PXle-5605 RF Downconverter Module | 9. 50 Ω Termination Loads (x3), Part Number 778353-01 |
| 3. PXle-5653 Synthesizer/LO Source Module | 10. Driver Software DVD |
| 4. Short, Semi-Rigid SMA-to-SMA Cable, Labeled K, Part Number 151612-01 | 11. Read Me First: Safety and Electromagnetic Compatibility |
| 5. Short, Silver Flexible RF SMA-to-SMA Cable (x3) Part Number 763718-01 | 12. Maintain Forced-Air Cooling Note to Users |
| 6. 3.6 GHz Version: Flexible 5-inch RF SMA-to-SMA Cable, Part Number 190412B-05. 14 GHz Version: Flexible 7-inch RF SMA-to-SMA Cable, Part Number 190412B-07. | 13. PXle-5665 Getting Started Guide (This Document) |
| 7. SMA Driver Bit, Part Number 190487A-01 | |
-

Other Equipment

There are several required items not included in your device kit that you need to install or operate the PXIe-5665.

Required Items

- A PXI Express chassis and chassis documentation. The PXIe-1075 chassis is one available option for your device. For more information about compatible chassis options, refer to [ni.com](#).
- A PXI Express embedded controller or MXI controller system that meets the system requirements specified in this guide and chassis documentation.

Optional Items

- A 1 N · m standard SMA torque wrench (NI part number 780487-01).
- (If you are using NI-RFSA 2.4) An SMA (m)-to-BNC (m) cable (part number 151890A-1R25). Use this cable to connect the REF OUT (10 MHz) connector on the PXIe-5653 front panel to the REF IN connector on the back of the PXI Express chassis. NI-RFSA versions 2.5 and later do not require this connection.

Preparing the Environment

Ensure that the environment you are using the PXIe-5665 in meets the following specifications.

| | |
|---|---|
| Operating ambient temperature (IEC 60068-2-1, IEC 60068-2-2) | 0 °C to 55 °C |
| Operating relative humidity (IEC 60068-2-56) | 10% to 90%, noncondensing |
| Maximum altitude | 2,000 m (800 mbar) (at 25 °C ambient temperature) |
| Pollution Degree | 2 |

Indoor use only.



Caution Clean the hardware with a soft, nonmetallic brush or lint free cloth. Make sure that the hardware is completely dry and free from contaminants before returning it to service.



Note Refer to the *PXIe-5665 Specifications* at [ni.com/manuals](#) for complete specifications.

Choosing and Installing the Software

Software Options

NI provides several software options for the PXIe-5665—NI-RFmx, the NI-RFSA instrument driver software, and the NI-RFSA Soft Front Panel (SFP).

Table 1. PXIe-5665 Software Options

| Software Option | Description | Use Case |
|---------------------------|---|--|
| NI-RFmx | Provides a single-handle instrument driver with built-in measurements. | Use NI-RFmx SpecAn to perform spectral measurements. Use NI-RFmx Demod to perform modulation quality measurements, such as EVM. Use NI-RFmx cellular personalities to perform physical layer measurement analysis on supported cellular signals. |
| NI-RFSA instrument driver | The NI-RFSA APIs each provide a fixed API for interacting with your PXIe-5665 device. NI-RFSA provides standard IVI-based functionality needed for most vector signal analyzer applications. | Use NI-RFSA to create custom measurements or applications that require I/Q data. Use NI-RFSA along with the NI Modulation Toolkit to analyze modulated signals to test receivers. |
| NI-RFSA SFP | Controls, analyzes, and presents data similar to stand-alone RF vector signal analyzers. The NI-RFSA SFP operates on the PC, so it provides processing, storage, and display capabilities. | Use the NI-RFSA SFP to interactively acquire data. |

Installing the Software

You must be an Administrator to install NI software on your computer.

1. Install an ADE, such as LabVIEW or LabWindows™/CVI™.
2. Insert the driver software media into your computer. The installer should open automatically.

If the installation window does not appear, navigate to the drive, double-click it, and double-click `autorun.exe`.

3. Follow the instructions in the installation prompts.



Note Windows users may see access and security messages during installation. Accept the prompts to complete the installation.

4. When the installer completes, select **Restart** in the dialog box that prompts you to restart, shut down, or restart later.

Installing the PXIe-5665



Caution To prevent damage to the PXIe-5665 caused by ESD or contamination, handle the module using the edges or the metal bracket.

You must install NI-RFSA before installing the hardware.

Before you install the hardware, refer to the guidelines in the *Maintain Forced-Air Cooling Note to Users* included with the module to ensure that the device can cool itself effectively.


To use the included cables, you must install the PXIe-5622 IF digitizer immediately to the left of the PXIe-5603 or PXIe-5605 RF downconverter module, and you must install the PXIe-5653 LO source module immediately to the right of the PXIe-5603 or PXIe-5605 RF downconverter module.

1. Ensure the AC power source is connected to the chassis before installing the module.

The AC power cord grounds the chassis and protects it from electrical damage while you install the module.

2. Power off the chassis.
3. Inspect the slot pins on the chassis backplane for any bends or damage prior to installation. Do not install a module if the backplane is damaged.
4. Remove the black plastic covers from all the captive screws on the module front panel.
5. Identify a supported slot in the chassis. The following figure shows the symbols that indicate the slot types.

Figure 2. Chassis Compatibility Symbols




- | | |
|---------------------------------------|-----------------------------------|
| 1. PXI Express System Controller Slot | 4. PXI Express System Timing Slot |
| 2. PXI Peripheral Slot | 5. PXI Express Peripheral Slot |
| 3. PXI Express Hybrid Peripheral Slot | |

PXIe-5665 modules can be placed in PXI Express peripheral slots, PXI Express hybrid peripheral slots, or PXI Express system timing slots.

6. Touch any metal part of the chassis to discharge static electricity.

7. Ensure that the ejector handle is in the downward (unlatched) position.
8. Place the module edges into the module guides at the top and bottom of the chassis. Slide the module into the slot until it is fully inserted.

Figure 3. Module Installation



1. Chassis
2. Hardware Module
3. Ejector Handle in Downward (Unlatched) Position

9. Latch the module in place by pulling up on the ejector handle.
10. Secure the module front panel to the chassis using the front-panel mounting screws.



Note Tightening the top and bottom mounting screws increases mechanical stability and also electrically connects the front panel to the chassis, which can improve the signal quality and electromagnetic performance.

11. Cover all empty slots using EMC filler panels or fill using slot blockers to maximize cooling air flow, depending on your application.
12. Power on the chassis.

Related Information

[Installing the Software](#) on page 6


Interconnecting the PXIe-5665 Modules

Complete the following steps to interconnect the PXIe-5665 front panel connectors using the PXIe-5603 downconverter, as shown in Figure 3, or the PXIe-5605 downconverter, as shown in Figure 4.



Caution The signal pins of this product's input/output ports can be damaged if subjected to ESD. To prevent damage, remove power from the product before connecting cables and employ industry-standard ESD prevention measures during installation, maintenance, and operation.


Figure 4. PXIe-5665 3.6 GHz Front Panel Interconnection



1. Short, Silver Flexible RF SMA-to-SMA Cable
2. Flexible RF SMA-to-SMA Cable

3. Short, Semi-Rigid SMA-to-SMA Cable, Labeled K
4. 50 Ω Termination Load

Figure 5. PXIe-5665 14 GHz Front Panel Interconnection



- | | |
|---|--|
| 1. Short, Silver Flexible RF SMA-to-SMA Cable | 3. Short, Semi-Rigid SMA-to-SMA Cable, Labeled K |
| 2. Flexible RF SMA-to-SMA Cable | 4. 50 Ω Termination Load |

- Using the three short, silver flexible RF SMA-to-SMA cables, connect the LO1, LO2, and LO3 connectors on the PXIe-5653 front panel to the associated LO1 IN, LO2 IN, and LO3 IN connectors on the PXIe-5605 or PXIe-5605 front panel.
- Using the flexible SMA-to-SMA cable, connect the REF OUT 100 MHz connector on the PXIe-5653 front panel to the CLK IN connector on the PXIe-5622 front panel.
- Using the short semi-rigid SMA-to-SMA cable (labeled K), connect the IF OUT connector on the PXIe-5605 or PXIe-5605 front panel to the IF IN connector on the PXIe-5622 front panel.
- Install a 50 Ω termination load on each of the PXIe-5605 or PXIe-5605 module LO1 OUT, LO2 OUT, and LO3 OUT connectors.
- Hand-tighten all SMA cable ends on the SMA connectors after the cable center pins are correctly aligned and connected. The cable connectors should tighten without much torque or effort. If a cable bends due to incorrect alignment, remove the cable from the front panel connector and reconnect the cable center pin on the SMA cable to the SMA connector.
- Carefully complete tightening all SMA connectors to 1 N · m using an appropriate torque wrench (not included) or torque screwdriver and SMA driver bit. Tighten only until the wrench clicks.



Caution Incorrect torque at SMA connections can degrade signal fidelity and phase-locked loop (PLL) performance and may cause insertion loss. Use an

appropriate torque wrench or torque screwdriver and SMA driver bit to ensure all SMA connections are properly torqued. SMA connectors for connections to external equipment may require torque different from 1 N · m, depending on the connector type, material, and manufacturer.

7. Power on the PXI Express chassis and controller system.
8. Verify that the ACCESS LED is on for all modules.

Related Information

[Troubleshooting](#) on page 27

If an issue persists after you complete a troubleshooting procedure, contact NI technical support or visit ni.com/support.

Refer to the [NI RF Vector Signal Analyzers Help](#) for information about how to connect the PXIe-5665 using an external clock or how to connect multiple PXIe-5665 modules.

Direct Connections to the PXIe-5603 or PXIe-5605

The PXIe-5603 or PXIe-5605 is a precision RF instrument that is sensitive to ESD and transients. Ensure you are making proper direct connections to the PXIe-5603 or PXIe-5605 to avoid damaging the device.



Caution Apply external signals only while the PXIe-5603 or PXIe-5605 is powered on. Applying external signals while the device is powered off may cause damage.

- Ensure you are properly grounded when manipulating cables or antennas connected to the PXIe-5603 or PXIe-5605 RF IN connector.
- If you are using noninsulated devices, such as an RF antenna, ensure the devices are maintained in a static-free environment.
- If you are using an active device, such as a preamplifier or switch routed to the PXIe-5603 or PXIe-5605 RF IN connector, ensure that the device cannot generate signal transients greater than the RF and DC specifications of the PXIe-5603 or PXIe-5605 RF IN connector.

PXIe-5603 or PXIe-5605 RF Downconverter Module Front Panel

The PXIe-5603 or PXIe-5605 RF downconverter module front panel contains eight connectors and two LEDs.

Figure 6. PXIe-5603 and PXIe-5605 RF Downconverter Module Front Panels




Table 2. Device Front Panel Icon Definitions

| | |
|--|--|
| | Refer to the user documentation for required maintenance measures to ensure user safety and/or preserve the specified EMC performance. |
| | The signal pins of this product's input/output ports can be damaged if subjected to ESD. To prevent damage, turn off power to the product before connecting cables and employ industry-standard ESD prevention measures during installation, maintenance, and operation. |

Table 3. PXIe-5603 or PXIe-5605 RF Downconverter Module Front Panel Connectors



| Connector | Use |
|-----------|---|
| RF IN | <p>Connects to the analog RF input signal to be measured by the PXIe-5665.</p> <p> Note The PXIe-5603 or PXIe-5605 downconverter module has no internal DC block. High-frequency components in the PXIe-5603 or PXIe-5605 can be damaged when DC signals are applied directly to the RF IN connector. The PXIe-5665 ships with an SMA DC block attached to the RF IN connector to prevent damage to the device when a DC input signal is present. The DC block must be removed to make measurements below 10 kHz. NI recommends that you keep the DC block attached to the RF IN connector for all measurements at frequencies greater than or equal to 10 kHz to maximize the accuracy of the device. If the RF attenuation is set to 0 dB with the DC block attached, an input DC voltage greater than ± 2 V may damage the internal components of the downconverter. To prevent damage to the downconverter, ensure that the DC voltage at the RF IN connector is between -2 VDC and +2 VDC. With the DC block removed, the maximum allowed voltage is 0 VDC.</p> <p> Caution To reinstall the DC block on the PXIe-5603 or PXIe-5605 RF IN connector, use a torque wrench set to a maximum torque of 0.79 N · m to 1.02 N · m (7 lb · in. to 9 lb · in.). Using more than the recommended amount of torque may damage the RF IN connector.</p> |
| IF OUT | <p>Connects to the IF IN connector on the PXIe-5622 module front panel.</p> <p>This connector is the output terminal for the frequency-translated IF signal. The IF OUT connector is rated at +22 dBm maximum, 0 VDC. The maximum safe voltage is 24 VDC.</p> |
| LO1 IN | <p>Connects to the LO1 OUT connector on the PXIe-5653 module front panel.</p> <p>This connector is the input terminal for the LO1 (3.2 GHz to 8.3 GHz) source. LO1 IN is an SMA connector with an impedance of 50 Ω (nominal) and a maximum safe power level of +15 dBm. The maximum safe voltage is 25 VDC.</p> |
| LO2 IN | <p>Connects to the LO2 OUT connector on the PXIe-5653 module front panel.</p> <p>This connector is the input terminal for the LO2 (4 GHz) source. LO2 IN is an SMA connector with an impedance of 50 Ω (nominal) and a maximum safe power level of +15 dBm. The maximum safe voltage is 25 VDC.</p> |

Table 3. PXIe-5603 or PXIe-5605 RF Downconverter Module Front Panel Connectors (Continued)

| Connector | Use |
|-----------|--|
| LO3 IN | <p>Connects to the LO3 OUT connector on the PXIe-5653 module front panel.</p> <p>This connector is the input terminal for the LO3 (800 MHz) source. LO3 IN is an SMA connector with an impedance of 50 Ω (nominal) and a maximum safe power level of +15 dBm. The maximum safe voltage is 25 VDC.</p> |
| LO1 OUT | <p>Output terminal for the LO1 (3.2 GHz to 8.3 GHz) source. In multichannel systems, LO1 OUT exports the signal received at LO1 IN to other PXIe-5603 or PXIe-5605 modules. LO1 OUT is disabled by default. LO1 OUT is an SMA connector with an impedance of 50 Ω (nominal) and a maximum safe power level of +15 dBm. The maximum safe voltage is 25 VDC.</p> |
| LO2 OUT | <p>Output terminal for the LO2 (4 GHz) source. In multichannel systems, LO2 OUT exports the signal received at LO2 IN to other PXIe-5603 or PXIe-5605 modules. LO2 OUT is disabled by default. LO2 OUT is an SMA connector with an impedance of 50 Ω (nominal) and a maximum safe power level of +15 dBm. The maximum safe voltage is 25 VDC.</p> |
| LO3 OUT | <p>Output terminal for the LO3 (800 MHz) source. In multichannel systems, LO3 OUT exports the signal received at LO3 IN to other PXIe-5603 or PXIe-5605 modules. LO3 OUT is disabled by default. LO3 OUT is an SMA connector with an impedance of 50 Ω (nominal) and a maximum safe power level of +15 dBm. The maximum safe voltage is 25 VDC.</p> |



Note LO1 OUT, LO2 OUT, and LO3 OUT enable phase-coherent operation of multiple devices by allowing you to use common LO signals when daisy-chaining the signals to other RF downconverter modules. When you are not using the LO OUT connectors, connect a 50 Ω termination load to each of these connectors.

Table 4. PXIe-5603 or PXIe-5605 RF Downconverter Module Front Panel LEDs

| LED | Indication |
|--------|--|
| ACCESS | <p>Indicates the basic hardware status of the module.</p> <p>OFF—The module is not yet functional, or the module has detected a problem with a power rail.</p> <p>AMBER—The module is being accessed. <i>Accessed</i> means that the device setup registers are being written to in order to control the device.</p> <p>GREEN—The module is ready to be programmed by NI-RFSA.</p> |
| ACTIVE | <p>Indicates the module state.</p> <p>OFF—The module is in a quiescent state.</p> <p>AMBER—The module is waiting for the Advance Trigger from the configuration list.</p> <p>GREEN—The module is triggered and is running a step from the configuration list.</p> <p>RED—The module has detected an error state. An error state may indicate the module has exceeded approved operating temperature and thermal shutdown has occurred or that the module has detected a power supply failure. If the power supply fails, contact NI technical support.</p> |

PXIe-5622 IF Digitizer Module

The PXIe-5622 IF digitizer module front panel contains four connectors and two LEDs.

Figure 7. PXIe-5622 IF Digitizer Module Front Panel




Table 5. Device Front Panel Icon Definitions



| | |
|---|--|
|  | Refer to the user documentation for required maintenance measures to ensure user safety and/or preserve the specified EMC performance. |
|  | The signal pins of this product's input/output ports can be damaged if subjected to ESD. To prevent damage, turn off power to the product before connecting cables and employ industry-standard ESD prevention measures during installation, maintenance, and operation. |

Table 6. PXIe-5622 IF Digitizer Module Front Panel Connectors

| Connector | Use |
|-----------|---|
| IF IN | <p>Connects to the IF OUT connector on the PXIe-5603 or PXIe-5605 RF downconverter module front panel.</p> <p>This connector is the input terminal for a frequency-translated IF waveform from the PXIe-5603 or PXIe-5605 RF downconverter for digitization and measurement.</p> |
| CLK IN | <p>Connects to the 100 MHz REF OUT connector on the PXIe-5653 LO source module.</p> <p>This connector is the input terminal for the Reference Clock or Sample Clock. CLK IN is an SMA connector with an input impedance of 50 Ω (nominal). The sine wave peak-to-peak input amplitude range is 0.63 V to 2.8 V (0 dBm to +13 dBm). The square wave peak-to-peak input amplitude range is 0.25 V to 2.8 V. The maximum peak-to-peak reference signal level is 6.3 V (+20 dBm) or damage can occur.</p> |
| CLK OUT | <p>This connector is the output terminal for the PXIe-5622 Reference Clock or Sample Clock. CLK OUT is an SMA connector with an output impedance of 50 Ω (nominal). The output power delivered to a 50 Ω load is >10 dBm.</p> |
| PFI 1 | <p>Receives a digital trigger from an external source. PFI 1 is an SMB connector and has an absolute voltage rating of -3.3 V to +8 V.</p> |

Table 7. PXIe-5622 IF Digitizer Module Front Panel LEDs

| LED | Indication |
|--------|--|
| ACCESS | <p>Indicates the basic hardware status of the module.</p> <p>OFF—The module is not yet functional, or the module has detected a problem with a power rail.</p> <p>AMBER—The module is being accessed. <i>Accessed</i> means that the device setup registers are being written to in order to control the device.</p> <p>GREEN—The module is ready to be programmed by NI-RFSA.</p> |
| ACTIVE | <p>Indicates the module state.</p> <p>OFF—The module is in a quiescent state.</p> <p>AMBER—The module is waiting for the Advance Trigger from the configuration list.</p> <p>GREEN—The module is triggered and is running a step from the configuration list.</p> <p>RED—The module has detected an error state. An error state may indicate the module has exceeded approved operating temperature and thermal shutdown has occurred or that the module has detected a power supply failure. If the power supply fails, contact NI technical support.</p> |

PXIe-5653 LO Source Module

The PXIe-5653 synthesizer/LO source module front panel contains six connectors and two LEDs.

Figure 8. PXIe-5653 Synthesizer/LO Source Module Front Panel




Table 8. Device Front Panel Icon Definitions




| | |
|---|--|
|  | Refer to the user documentation for required maintenance measures to ensure user safety and/or preserve the specified EMC performance. |
|  | The signal pins of this product's input/output ports can be damaged if subjected to ESD. To prevent damage, turn off power to the product before connecting cables and employ industry-standard ESD prevention measures during installation, maintenance, and operation. |
|  | If this device has been in use, it may exceed safe handling temperatures and cause burns. Allow the device to cool before removing it from the chassis. |

Table 9. PXIe-5653 Synthesizer/LO Source Front Panel Connectors

| Connector | Use |
|-------------------|---|
| REF IN | Routes a frequency reference signal to the RF synthesizer/LO source. This connector accepts a 10 MHz frequency signal with a maximum voltage of 2 V _{pk-pk} . |
| REF OUT (10 MHz) | Routes a frequency reference signal from the synthesizer/LO module onboard 10 MHz oven-controlled crystal oscillator (OCXO). |
| REF OUT (100 MHz) | Connects to the CLK IN connector on the PXIe-5622 front panel. This connector routes a frequency reference signal from the synthesizer onboard 100 MHz OCXO. |
| LO1 OUT | Connects to the LO1 IN connector on the PXIe-5603 or PXIe-5605 module front panel. This connector is the output terminal for the LO1 (3.2 GHz to 8.3 GHz) source. LO1 OUT is an SMA connector with an impedance of 50 Ω (nominal). |

Table 9. PXIe-5653 Synthesizer/LO Source Front Panel Connectors (Continued)

| Connector | Use |
|-----------|---|
| LO2 OUT | <p>Connects to the LO2 IN connector on the PXIe-5603 or PXIe-5605 module front panel.</p> <p>This connector is the output terminal for the LO2 (4 GHz) source. LO2 OUT is an SMA connector with an impedance of 50 Ω (nominal).</p> |
| LO3 OUT | <p>Connects to the LO3 IN connector on the PXIe-5603 or PXIe-5605 module front panel.</p> <p>This connector is the output terminal for the LO3 (800 MHz) source. LO3 OUT is an SMA connector with an impedance of 50 Ω (nominal).</p> |

Table 10. PXIe-5653 Synthesizer/LO Source Front Panel LEDs

| LED | Indications |
|--------|--|
| ACCESS | <p>Indicates the basic hardware status of the module.</p> <p>OFF—The module is not yet functional, or the module has detected a problem with a power rail.</p> <p>AMBER—The module is being accessed. <i>Accessed</i> means that the device setup registers are being written to in order to control the device.</p> <p>GREEN—The module is ready to be programmed by NI-RFSA.</p> |
| ACTIVE | <p>Indicates the state of the module.</p> <p>OFF—The module is not generating a signal.</p> <p>AMBER—The module phased-locked loops (PLLs) are attempting to lock.</p> <p>GREEN—The module is generating a signal; applicable PLLs are locked.</p> <p>RED—The module has detected an error state. An error state may indicate the module detects a PLL lock failure, is exceeding approved operating temperature and is in a state of thermal shutdown, or the module detects a power supply failure. If the power supply fails, contact NI technical support.</p> |



Note The PXIe-5653 LO source has 10 MHz and 100 MHz reference outputs. For best performance, connect the 100 MHz REF OUT connector to the PXIe-5622 CLK IN connector.

Configuring the PXIe-5665 in MAX

Use Measurement & Automation Explorer (MAX) to configure your NI hardware. MAX informs other programs about which NI hardware products are in the system and how they are configured. MAX is automatically installed with NI-RFSA.

1. Launch MAX.
2. In the configuration tree, expand **Devices and Interfaces** to see the list of installed NI hardware.



Note If you are using the PXIe-5665 with the LabVIEW Real-Time Module, expand **Remote Systems**. Find your target IP address or name, expand it, and then expand **Devices and Interfaces**.

Installed modules appear under the name of their associated chassis.

3. Expand your **Chassis** tree item.

MAX lists all modules installed in the chassis. Your default names may vary.



Note If you do not see your module listed, press <F5> to refresh the list of installed modules. If the module is still not listed, power off the system, ensure the module is correctly installed, and restart.

4. Record the identifier MAX assigns to the hardware. Use this identifier when programming the PXIe-5665.
5. Associate the hardware modules that comprise your device.
 - a) Select the PXIe-5603 or PXIe-5605 that is identified as not configured in the configuration tree.
 - b) In the Associated Devices section, select the appropriate module from each system component drop-down listbox.

For the PXIe-5665, you must associate the PXIe-5622 IF digitizer module and the PXIe-5653 LO source module with the PXIe-5603 or PXIe-5605 RF downconverter.

- c) Click **Save** in the MAX toolbar.



Note Module associations may be lost when you move the modules to different chassis slots.

6. Self-test the device modules by selecting the modules in the configuration tree, and clicking **Self-Test** in the MAX toolbar. Repeat this step for all modules in your PXIe-5665 system.

The MAX self-test performs a basic verification of hardware resources.

Related Information

[Troubleshooting](#) on page 27

If an issue persists after you complete a troubleshooting procedure, contact NI technical support or visit ni.com/support.

[Interconnecting the PXIe-5665 Modules](#) on page 8

[Refer to the NI RF Vector Signal Analyzers Help for more information about renaming devices.](#)

Self-Calibration

It is important to perform a self-calibration after first connecting your system because of cabling and mismatch effects and some degree of residual error, which result from module interconnections. You can determine and reduce these undesired effects through self-calibration, which adjusts the PXIe-5665 with respect to an onboard high-precision calibration tone. Additionally, you should periodically run a self-calibration to adjust for performance drifts that occur with product aging.

The PXIe-5665 modules are independently calibrated at the factory; however, you should perform a self-calibration in any of the following situations:

- After first installing and interconnecting your PXIe-5665 system
- When there is a physical change to any of the system components, such as replacement of modules
- When there is a change to the system cabling
- When the system is in an environment where external variables, such as temperature, can affect measurements

You should also perform a self-calibration if your device has exceeded any of the following temperature or time limits since the last device self-calibration:

- IF flatness: $\pm 5^{\circ}\text{C}$ and/or 7 days
- Gain reference: $\pm 5^{\circ}\text{C}$ and/or 7 days
- LO self-calibration: $\pm 10^{\circ}\text{C}$ and/or 30 days
- Digitizer self-calibration: $\pm 5^{\circ}\text{C}$ and/or 90 days
- Preselector alignment (PXIe-5605 only): $\pm 5^{\circ}\text{C}$ and/or 7 days

Performing a Device Self-Calibration Using the NI-RFSA SFP

NI recommends you run the self-calibration from the NI-RFSA SFP. You can also run a self-calibration programmatically using the NI-RFSA API.

1. Launch the NI-RFSA SFP by navigating to **Start»All Programs»National Instruments»NI-RFSA»NI-RFSA Soft Front Panel**.
2. Click **Device/System»Calibration»Self Calibration**.
3. Select the self-calibration steps you want to perform from the **Self-Calibration** dialog box.

4. Click **Next** to run the self-calibration.

Locating the Software and Examples

Software Locations

Table 11. Locations of NI-RFmx Software

| ADE | Location |
|------------------------|--|
| LabVIEW | Available on the LabVIEW Functions palette at Measurement I/O»NI-RFmx . |
| LabWindows/CVI | NI-RFmx functions are available from the LabWindows/CVI Library menu at Library»RFmx SpecAn Library and Library»RFmx Demod Library . |
| Microsoft Visual C/C++ | <p>Use the header files located in the <NIDir>\Shared\ExternalCompilerSupport\C\include directory and import library files located in one of the following directories:</p> <ul style="list-style-type: none">• Windows 10 (32-bit)/8.1 (32-bit)/7 (32-bit)—<NIDir>\Shared\ExternalCompilerSupport\C\include• Windows 10 (64-bit)/8.1 (64-bit)/7 (64-bit):<ul style="list-style-type: none">– 32-bit installation—<NIDir>\Shared\ExternalCompilerSupport\C\lib32\msvc– 64-bit installation—<NIDir>\Shared\ExternalCompilerSupport\C\lib64\msvc <p>where <NIDir> is one of the following locations:</p> <ul style="list-style-type: none">• Windows 10 (32-bit)/8.1 (32-bit)/7 (32-bit)—Program Files\National Instruments• Windows 10 (64-bit)/8.1 (64-bit)/7 (64-bit)—Program Files (x86)\National Instruments |
| Microsoft .NET | For the location of .NET class libraries, refer to the installed NI-RFmx readme. |

Table 12. Locations of NI-RFSA and NI-RFSA SFP Software

| Software Option | ADE | Location |
|-----------------|------------------------|--|
| NI-RFSA | LabVIEW | Available on the LabVIEW Functions palette at Measurement I/O»NI-RFSA . |
| | LabWindows/CVI | Available in the <code><IVIROOTDIR32>\Drivers\niRFSA</code> directory, where <code><IVIROOTDIR32></code> is one of the following locations: <ul style="list-style-type: none"> Windows 10 (32-bit)/8.1 (32-bit)/7 (32-bit) —Program Files\IVI Foundation\IVI Windows 10 (64-bit)/8.1 (64-bit)/7 (64-bit) —Program Files (x86)\IVI Foundation\IVI |
| | Microsoft Visual C/C++ | Use the header files located in the <code><IVIROOTDIR32>\Include</code> directory and import library files located in the <code><IVIROOTDIR32>\Lib</code> directory, where <code><IVIROOTDIR32></code> is one of the following directories: <ul style="list-style-type: none"> Windows 10 (32-bit)/8.1 (32-bit)/7 (32-bit) —Program Files\IVI Foundation\IVI Windows 10 (64-bit)/8.1 (64-bit)/7 (64-bit) —Program Files (x86)\IVI Foundation\IVI |
| | Microsoft .NET | To use the .NET API, you must install the .NET class libraries. For download and installed file locations, visit ni.com/info and enter Info Code NETAPIdriversupport. |

Table 12. Locations of NI-RFSA and NI-RFSA SFP Software (Continued)

| Software Option | ADE | Location |
|-----------------|---------|--|
| NI-RFSA SFP | LabVIEW | Available from the Start Menu at Start»All Programs»National Instruments»NI-RFSA»NI-RFSA Soft Front Panel . |

Related Information

Refer to the [Getting Started with NI-RFSA](#) section of the [NI RF Vector Signal Analyzers Help](#) for detailed instructions about how to acquire data in a specific ADE.

Refer to the [Creating an Application with Microsoft Visual C and C++](#) topic of the [NI RF Vector Signal Analyzers Help](#) if you prefer to manually add all required include and library files to the project.

Programming Examples Locations

Using the NI Example Finder

If you're using NI-RFmx or NI-RFSA with LabVIEW or LabWindows/CVI, use the NI Example Finder to locate programming examples.

1. Launch LabVIEW or LabWindows/CVI.
2. Select **Help»Find Examples** to open the NI Example Finder.
3. Navigate to **Hardware Input and Output»Modular Instruments**.
4. Open the example that best matches your application requirements.

Using Microsoft Visual C/C++

If you're using NI-RFmx or NI-RFSA with Microsoft Visual C/C++, locate examples in the following directories.

Table 13. Location of Microsoft Visual C/C++ Programming Examples

| Software Option | Examples Location |
|-----------------|---|
| NI-RFmx | <code><NIDocDir>\RFmx\Demod\Examples</code> <code><NIDocDir>\RFmx\SpecAn\Examples</code> where <code><NIDocDir></code> is the Users\Public\Public Documents \National Instruments directory. |
| NI-RFSA | <code><NIDocDir>\NI-RFSA\examples</code> where <code><NIDocDir></code> is the Users\Public\Public Documents \National Instruments directory. |



Note LabVIEW examples that demonstrate integration of the PXIe-5665 with NI RF vector signal generators and NI toolkit software, including the NI Modulation Toolkit, are also available online at ni.com/examples.

Troubleshooting

If an issue persists after you complete a troubleshooting procedure, contact NI technical support or visit ni.com/support.

Installation

Why Is the ACCESS LED Off When the Chassis Is On?

The LEDs may not light until the device has been configured in MAX. Before proceeding, verify that the PXIe-5665 appears in MAX.

If the ACCESS LED fails to light after you power on the chassis, a problem may exist with the chassis power rails, a hardware module, or the LED.



Caution Apply external signals only while the PXIe-5665 is powered on. Applying external signals while the device is powered off may cause damage.

1. Disconnect any signals from the module front panels.
2. Power off the chassis.
3. Remove the module from the chassis and inspect it for damage. Do not reinstall a damaged device.
4. Reinstall the module in a different chassis slot.

5. Power on the chassis.
6. Verify that the device appears in MAX.
7. Reset the device in MAX and perform a self-test.

What Should I Do if the PXIe-5665 Doesn't Appear in MAX?

1. In the MAX configuration tree, expand **Devices and Interfaces**.
2. Expand the **Chassis** tree to see the list of installed hardware, and press <F5> to refresh the list.
3. If the module is still not listed, power off the system, ensure that all hardware is correctly installed, and restart the system.
4. Navigate to the Device Manager.

| Operating System | Description |
|-----------------------|--|
| Windows 10/8.1 | Right-click the Start button, and select Device Manager . |
| Windows 7 | Select Start»Control Panel»Device Manager . |

5. Verify the PXIe-5665 appears in the Device Manager.
 - a) Under an NI entry, confirm that a PXIe-5665 entry appears.



Note If you are using a PC with a device for PXI remote control system, under **System Devices**, also confirm that no error conditions appear for the **PCI-to-PCI Bridge**.

- b) If error conditions appear, reinstall NI-RFSA and the PXIe-5665.

What Should I Do if the PXIe-5665 Fails the Self-Test?

1. Restart the system.
2. Launch MAX, and perform the self-test again.
3. Power off the chassis.
4. Reinstall the failed module in a different slot.
5. Power on the chassis.
6. Perform the self-test again.

Configuration

What Should I Do if the Device Does Not Initialize?

Failure to initialize may indicate a problem with module interconnections or with MAX. If the niRFSA Initialize VI or the niRFSA_init function returns an error and the PXIe-5665 fails to initialize, complete the following steps:

1. Reconnect the PXIe-5665 hardware module front panel cables securely.

2. Power on your system and run the MAX configuration and self-test procedures.

Related Information

[Interconnecting the PXIe-5665 Modules](#) on page 8

[Configuring the PXIe-5665 in MAX](#) on page 22

What Should I Do if the PXIe-5622 IF Digitizer Module Does Not Phase-Lock to the PXIe-5653 LO Source Module?

If the PXIe-5622 IF digitizer module fails to phase-lock to the PXIe-5653 LO source module internal reference through the front panel, complete the following steps:

1. Verify that the cable is not faulty and that all cables are connected to the correct terminals.
2. Verify that there is a reference signal generated from the PXIe-5653 REF OUT 100 MHz front panel connector.

If there is a 100 MHz signal coming from the PXIe-5653 REF OUT 100 MHz front panel connector, the PXIe-5622 phase-lock circuitry may be at fault.

If failures continue and there is no signal at these output terminals, there may be a problem with the PXIe-5653 hardware. Contact NI technical support or visit ni.com/support.

What Should I Do if the NI-RFSA Soft Front Panel Does Not Launch?

1. Verify the front panel interconnections for your RF vector signal analyzer.
2. Verify the MAX device association for your PXIe-5665.
3. If you have verified the interconnections and associations of your device and you are still unable to launch the NI-RFSA SFP, try uninstalling and then reinstalling NI-RFSA.

Related Information

[Interconnecting the PXIe-5665 Modules](#) on page 8

[Configuring the PXIe-5665 in MAX](#) on page 22

Measurements

What Should I Do if the Device Amplitude Reading Does Not Match the Source?


1. Verify that the discrepancy between the PXIe-5665 and the source is within the error limits of the devices.
 - a) Verify the absolute amplitude accuracy of the PXIe-5665 using the appropriate value.
 - b) Verify the level accuracy of the input signal into the receiver.
2. Check for cable loss, which can be substantial. For example, an RG58 coaxial cable loses about 2.1 dB of signal amplitude per foot at 2 GHz. Unless you are using high-quality cables, expect losses when working with high-frequency signals.

3. Perform a self-calibration for the PXIe-5665.

If errors continue, contact NI technical support or visit ni.com/support.

Where to Go Next

Refer to the following figure for information about other product tasks and associated resources for those tasks.



Tip The *NI RF Vector Signal Analyzers Help* is an HTML version of a traditional user manual that includes detailed information about RF fundamentals, device features, and programming with NI-RFSA.

Worldwide Support and Services

The NI website is your complete resource for technical support. At ni.com/support, you have access to everything from troubleshooting and application development self-help resources to email and phone assistance from NI Application Engineers.

Visit ni.com/services for NI Factory Installation Services, repairs, extended warranty, and other services.

Visit ni.com/register to register your NI product. Product registration facilitates technical support and ensures that you receive important information updates from NI.

A Declaration of Conformity (DoC) is our claim of compliance with the Council of the European Communities using the manufacturer's declaration of conformity. This system affords the user protection for electromagnetic compatibility (EMC) and product safety. You can obtain the DoC for your product by visiting ni.com/certification. If your product supports calibration, you can obtain the calibration certificate for your product at ni.com/calibration.

NI corporate headquarters is located at 11500 North Mopac Expressway, Austin, Texas, 78759-3504. NI also has offices located around the world. For telephone support in the United States, create your service request at ni.com/support or dial 1 866 ASK MYNI (275 6964). For telephone support outside the United States, visit the *Worldwide Offices* section of ni.com/global to access the branch office websites, which provide up-to-date contact information, support phone numbers, email addresses, and current events.

Information is subject to change without notice. Refer to the *NI Trademarks and Logo Guidelines* at ni.com/trademarks for information on NI trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering NI products/technology, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your media, or the *National Instruments Patent Notice* at ni.com/patents. You can find information about end-user license agreements (EULAs) and third-party legal notices in the `readme` file for your NI product. Refer to the *Export Compliance Information* at ni.com/legal/export-compliance for the NI global trade compliance policy and how to obtain relevant HTS codes, ECCNs, and other import/export data. NI MAKES NO EXPRESS OR IMPLIED WARRANTIES AS TO THE ACCURACY OF THE INFORMATION CONTAINED HEREIN AND SHALL NOT BE LIABLE FOR ANY ERRORS. U.S. Government Customers: The data contained in this manual was developed at private expense and is subject to the applicable limited rights and restricted data rights as set forth in FAR 52.227-14, DFAR 252.227-7014, and DFAR 252.227-7015.

© 2010—2017 National Instruments. All rights reserved.

375604K-01 August 18, 2017