COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

0

1-800-915-6216

www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



NI-9237



Board Assembly Part Number(s)

Part Number	Description
198859D-01L	NI 9237 4-CH BRIDGE ANALOG INPUT MODULE RJ50
198855B-01L	NI 9237 4-CH BRIDGE ANALOG INPUT MODULE DSUB
198855B-03L	NI 9237 4-CH BRIDGE ANALOG INPUT MODULE DSUB WITH CONFORMAL COATING

Manufacturer: National Instruments

Volatile Memory

Type	Size	User Accessible/ System Accessible ¹	Battery Backup?	Purpose	Method of Clearing ²		
ADC	(x4) 24bits	Yes/Yes	No	Stores last digitized value	Cycle power		
CPLD RAM	2 bytes	No/Yes	No	Stores Module Configuration	<i>y</i> 1		
Non-Volatile Memory							
Type	Size	User Accessible/ System Accessible	Battery Backup?	Purpose	Method of Clearing		
EEPROM	1 KB	No/Yes	No	Module ID and Calibration ³	None available to user		
CPLD	440 Macrocell	No/No	No	Module Operation	None available to user		
Media Storage							
_	~	User Accessible/	Battery	_			
Type	Size	System Accessible	Backup?	Purpose	Method of Clearing		

NONE

Clearing Notes:

EEPROM: User accessibility of the calibration EEPROM is exposed through an external calibration Applications Programming Interface (API) in LabVIEW. To declassify this memory, complete the steps listed in KB <u>4GHLANQE</u> (Clearing the User-Accessible EEPROM on an NI-DAQmx Supported Device).

January 2016 375831A-01 Contact: 866-275-6964 support@ni.com

Items are designated **No** for the following reason(s):

a) Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed.

b) Hardware-modifying software tools are not distributed to customers for any personal access or customization, also known as non-normal use.

² The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to clear the memory are not distributed by National Instruments to customers for normal use

Calibration constants that are stored in device EEPROMs include information for the device's full operating range. Calibration constants do not maintain any unique data for specific configurations at which the device is used unless otherwise specified.



Terms and Definitions

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

System Accessible Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

Cycle Power The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

Non-Volatile Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.