COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

0

1-800-915-6216

www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



SCXI-1193

Contact: 866-275-6964

support@ni.com



Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
188577A-01 or later	SCXI-1193 RF Multiplexer Switch

Volatile Memory

Target Data	Туре	Size	Battery Backup	User ¹ Accessible	System Accessible	Sanitization Procedure
Switching Scanlist	SRAM	128KB	No	No	Yes	Cycle Power
Digital Logic Controller	FPGA Block RAM	5KB	No	No	Yes	Cycle Power

Non-Volatile Memory (incl. Media Storage)

Target Data	Туре	Size	Battery Backup	User Accessible	System Accessible	Sanitization Procedure
Relay Count	EEPROM	16KB	No	Yes	Yes	Procedure 2
Reserved Storage	EEPROM	16KB	No	No	Yes	None
Reserved Storage	EPROM	212KB	No	No	Yes	None
Relay Drivers	CPLD	64	No	No	Yes	None
		Macrocells				

¹ Refer to Terms and Definitions section for clarification of User and System Accessible

Contact: 866-275-6964

support@ni.com



Procedures

Procedure 1 –Board Assembly Part Number Identification:

To determine the Board Assembly Part Number and Revision, refer to the label applied to the surface of your product. The Assembly Part Number should be formatted as "PART NO: ######A-##L".

Procedure 2 – Non-Volatile Memory, Relay Counts

- 1. Open NI-SWITCH Soft Front Panel
- 2. Select the desired device from "Device" pull down menu
- 3. Select File >> Relay Maintenance
- 4. Select the desired relay from the "Relay Name" pull down menu
- 5. Check the "Edit Count" box
- 6. Enter 0 for New Relay Count
- 7. Click OK
- 8. Repeat steps 1-7 for each desired relay

Contact: 866-275-6964

support@ni.com



Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per NIST Special Publication 800-88 Revision 1, "clearing" is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per NIST Special Publication 800-88 Revision 1, "sanitization" is a process to render access to "Target Data" on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.