COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs. We Sell For Cash We Get Credit We Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.

APEX WAVES

Bridging the gap between the manufacturer and your legacy test system.

1-800-915-6216
www.apexwaves.com
sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote CLICK HERE NI-9760

USER MANUAL

NI Powertrain Controls VR/Hall Sensor Module (Rev C)



Contents

Introduction	Ĺ
Pinout	<u>,</u>
Hardware	2
Powering the Module	2
Platform Compatibility	3
Input Channels Used for VR Sensor Inputs	3
Input Channels Used for Hall-Effect Sensor Inputs	5
Custom Configuration ϵ	5
Physical Specifications and Characteristics	5
Electrical Specifications and Characteristics	5
Compliance and Certifications	7



Introduction

The National Instruments 9760 CompactRIO VR/Hall Sensor Module offers a set of automotive style inputs to interface with standard automotive position sensors. It provides six channels which may be software selected as a VR sensor or a Hall-Effect sensor input.

Features

- 6 channels software configured as VR sensor or Hall-Effect sensor inputs
 - 600 kHz lowpass filter
 - VR sensor inputs
 - ±60 V input range
 - Adaptive/manually programmable arming thresholds
 - Hall-effect sensor or general purpose digital inputs
 - Over/under voltage protection
 - Optional software selectable pull-up resistor
- External output for each channel according to software configuration
- Sensor Power output: 5 V @ 200 mA
- LabVIEW FPGA and LabVIEW Real Time VIs for quick integration with application

Pinout



Figure 1. Pin Assignments NI 9760

Hardware

NI recommends using the NI 9923 Connector Kit for connections to the NI 9760. The NI 9923 provides proper strain relief for NI 9760 connections. Visit ni.com/info and enter Info Code VRHALL for more information on parts and accessories for the NI 9760

Powering the Module

The CompactRIO backplane male high density DSUB 15-pin (HD15) connector, which mates with the female HD15 connector on the module. This power source provides a regulated 5 V and ground to various digital logic functions. The CompactRIO 5 V source is active whenever the CompactRIO or R Series Expansion Chassis is properly powered. You can power the NI 9760 only at the HD15 connector by plugging it into a CompactRIO or R Series Expansion Chassis. Do not connect the HD15 connector to any other device.

If the 5V OUT lines or internal pull-up resistors are to be used for Hall-effect sensors, then the external DB-37 connector pins labeled 5-30V IN (19) and GND (36) must be connected to an external supply of 5V to 30V. The module is reverse battery protected to -30V. The NI 9760 external power ground and CompactRIO backplane power ground are isolated and have no internal connection.



Caution The external battery supply input terminals are reverse voltage protected to -30 V. Connecting the NI 9760 in reverse polarity at voltages greater than -30 V or forward polarity at greater than +30 V will result in damage. This event is not covered by warranty.

Platform Compatibility

NI Powertrain Control modules require a hardware support system to function. You cannot use the modules independently or interfaced with third-party devices at the backplane HD15 connector. NI Powertrain Control modules are compatible with the following National Instruments platforms:

- CompactRIO, which consists of a CompactRIO controller, chassis, or integrated controller/chassis.
- NI PXI, which consists of any NI PXI chassis, NI PXI RT controller, and NI PXI-78xxR R Series FPGA card. The NI Powertrain Control modules insert into an NI R Series expansion chassis. Connect an NI R Series expansion chassis to the NI PXI FPGA card using a SHC68-68-RDIO cable.
- MXI-Express, Ethernet and EtherCAT expansion chassis.



Note NI Powertrain Control modules are not compatible with the National Instruments CompactDAQ chassis.



Note NI Powertrain Control modules do not support Scan Interface mode.

Input Channels Used for VR Sensor Inputs

The VR Hall module provides up to six identical VR sensor inputs. A Variable Reluctance (VR) sensor is a standard production automotive speed sensor. It is an electromagnetic sensing device containing a winding of wire around a permanent magnetic core. It relies on the movement of ferrous material (steel teeth) past the tip of the sensor to change the magnetic flux of the sensor. This creates a voltage pulse across the leads of the sensor's wire coil. Figures 4 and 5 below show a typical VR signal with respect to toothed wheels, as shown in figures 2 and 3. The VR signal will go positive as a tooth approaches the sensor tip. The signal will then rapidly swing back through zero precisely at the center of the tooth. As the tooth moves away from the sensor tipthe voltage will continue in the negative direction and then return to zero.











Figure 5. Incorrect Signal Polarity for VR Input Circuit



Each VR sensor input requires two connections. The VR Hall module pins labeled IN 1+ through IN 6+ are the positive sensor inputs. The negative sensor inputs must be connected module pins labeled IN 1- through IN 6-. The polarity of the sensor connection to the module is critical. The leads of the sensor should be connected such that the positive input of the VR circuit sees the waveform shown in Figure 4. The waveform shown Figure 5 is incorrect, and the VR circuit will not properly respond to this waveform. The rapid zero crossing of the VR signal must be in the negative direction.

The polarity of the physical tooth or gap on the trigger wheel will contribute to the polarity of the voltage pulse from the sensor. Figure 2 demonstrates a positive physical tooth polarity and Figure 3 demonstrates a negative physical tooth polarity. Assuming the lead polarity of a sensor remained the same, one of the configurations would generate the waveform shown in Figure 4, while the other configuration would generate the waveform shown in Figure 5. Triggers wheels are designed so that the physical center of each tooth or gap corresponds to a known angular position of the wheel. This physical center of the tooth or gap always corresponds to the rapid zero-crossing of the generated voltage pulse.

The VR circuit is designed so that the rapid negative zero-crossing of the raw sensor signal corresponds to the rising edge of a digital pulse sent to the RIO FPGA. The VR output signal to the FPGA will go TRUE at the rapid negative zero crossing of the external VR pulse and remain TRUE until the external VR pulse rises above the arming threshold voltage. An example of this is shown in Figure 6. Within LabVIEW FPGA the system designer can route this digital signal to the EPT CrankSig or CamSig input. The signal can also be routed to any other speed measurement sub-VI.



The absolute maximum VR pulse amplitude allowed by the circuit is ± 60 V. If the input signal exceeds this voltage, damage may occur to the circuit. The amplitude should not exceed ± 60 V at maximum engine speed. The minimum VR pulse amplitude that will generate a digital output by the VR circuit is ± 30 mV.

The VR circuit implements adaptive noise rejection features during continuous incoming VR pulses while in adaptive threshold mode. In general, an adaptive arming threshold voltage is generated with each VR pulse at 33% of the previous pulse amplitude. The next pulse must have an amplitude that exceeds the arming threshold in order for a digital output to be generated at the rapid zero-crossing. If no arming event occurs for 85ms, the arming threshold is reset to 30 mV.

Alternately, a manually set arming threshold can be defined.

Given a constant gap between the sensor and the trigger teeth, the amplitude of a VR pulse is directly proportional to the speed of the trigger wheel. For example, if the VR amplitude at 1000 RPM is ± 10 V, then the amplitude at 2000 RPM will be ± 20 V. By using an oscilloscope to measure the VR amplitude at a low speed, this relationship can be used to determine what the maximum amplitude will be at the maximum speed. If the maximum amplitude of ± 60 V will be exceeded at maximum speed, then the sensor gap must be increased.

Input Channels Used for Hall-Effect Sensor Inputs

The VR Hall module provides up to six identical hall-effect sensor input circuits. When using hall sensors, the ground of the sensor should be connected to the IN - side of an input channel and one of the GND pins. If the hall sensor has an opencollector output, requiring a pull-up resistor at the collector, a pull-up resistor can be engaged through software. You must use an external power supply to use the pull-up resistor.

The circuit's output to the RIO FPGA goes high when the input voltage is greater than the manually set threshold voltage. The output goes low when the input is less than the manually set threshold voltage.

Custom Configuration

 $Visit \verb"ni.com/info"$ and enter Info Code <code>ADCOMBO</code> for more information about custom configuration.

Physical Specifications and Characteristics

Weight	. 170 g
Maximum Altitude	. 2000 m
Operating Temperature	40 °C to 60 °C
Maximum Ambient Temperature	. 60 °C
Operating Humidity	. 10% to 90% RH, non-condensing
Pollution Degree	.2
Ingress Protection	. IP40
For indoor use only.	

If you need to clean the module, wipe it with a dry towel.

Electrical Specifications and Characteristics

External Power

5 to 30 VDC Max
30 V
5 V 3%, Vsup 6 V

Inputs

Arming Threshold Digital to Analog Conversion Range	0 to 4.096
Arming threshold Digital to Analog Resolution	10 bit
Arming Threshold Range (Differential Voltage at ExternalPins)	0 to 2.97V
Lowpass Filter	600 kHz
Lag time From VR Neg. Zero Crossing	
Event to Digital Output Rising Edge	3 us
Peak Voltage	±60V
Outputs	
Voltage Standard	5 V TTI

voltage Standard			
Reverse Polarity	Protection	±8 mA	١

Safety Guidelines



Caution Do not operate this module in a manner not specified in these operating instructions. Do not exceed the 60VDC rating. Product misuse can result in a hazard. You can compromise the safety protection built into the product if the product is damaged in any way. If the product is damaged, return it to National Instruments for repair.

Compliance and Certifications

Safety

This product meets the requirements of the following standards of safety for electrical equipment for measurement, control, and laboratory use:

- IEC 61010-1, EN 61010-1
- UL 61010-1, CSA 61010-1

Electromagnetic Compatibility

This product meets the requirements of the following EMC standards for electrical equipment for measurement, control, and laboratory use:

- EN 61326-1 (IEC 61326-1): Class A emissions; Industrial immunity
- EN 55011 (CISPR 11): Group 1, Class A emissions
- AS/NZS CISPR 11: Group 1, Class A emissions
- FCC 47 CFR Part 15B: Class A emissions
- ICES-001: Class A emissions



Caution When operating this product, use shielded cables and accessories.

CE Compliance $\mathbf{C}\mathbf{\epsilon}$

This product meets the essential requirements of applicable European Directives as follows:

- 2006/95/EC; Low-Voltage Directive (safety)
- 2004/108/EC; Electromagnetic Compatibility Directive (EMC)

Environmental Management

NI is committed to designing and manufacturing products in an environmentally responsible manner. NI recognizes that eliminating certain hazardous substances from our products is beneficial to the environment and to NI customers.

For additional environmental information, refer to the *Minimize Our Environmental Impact* web page at ni.com/environment. This page contains the environmental regulations and directives with which NI complies, as well as other environmental information not included in this document.

Waste Electrical and Electronic Equipment (WEEE)



EU Customers At the end of the product life cycle, all products *must* be sent to a WEEE recycling center. For more information about WEEE recycling centers, National Instruments WEEE initiatives, and compliance with WEEE Directive 2002/96/EC on Waste and Electronic Equipment, visit ni.com/environment/weee.

Battery Replacement and Disposal



Battery Directive This device contains a long-life coin cell battery. If you need to replace it, use the Return Material Authorization (RMA) process or contact an authorized National Instruments service representative. For more information about compliance with the EU Battery Directive 2006/66/EC about Batteries and Accumulators and Waste Batteries and Accumulators, visit ni.com/environment/batterydirective.

电子信息产品污染控制管理办法 (中国 RoHS)

中国客户 National Instruments 符合中国电子信息产品中限制使用某些有害物质指令 (RoHS)。关于 National Instruments 中国 RoHS 合规性信息,请登录 ni.com/ environment/rohs_china。(For information about China RoHS compliance, go to ni.com/environment/rohs_china.)

Refer to the *NI Trademarks and Logo Guidelines* at ni.com/trademarks for more information on NI trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering NI products/technology, refer to the appropriate location: Help>Patents in your software, the patents.txt file on your media, or the *National Instruments Patents Notice* at ni.com/patents.You can find information about end-user license agreements (EULAs) and third-party legal notices in the readme file for your NI product. Refer to the *Export Compliance Information* at ni.com/legal/export-compliance for the NI global trade compliance policy and how to obtain relevant HTS codes, ECCNs, and other import/export data. NI MAKES NO EXPRESS OR IMPLIED WARRANTIES AS TO THE ACCURACY OF THE INFORMATION CONTAINED HEREIN AND SHALL NOT BE LIABLE FOR ANY ERRORS. U.S. Government Customers: The data contained in this manual was developed at private expense and is subject to the applicable limited rights and restricted data rights as set forth in FAR 52.227-14, DFAR 252.227-7014, and DFAR 252.227-7015.

© 2016 National Instruments. All rights reserved.