

## COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

## SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash    Get Credit    Receive a Trade-In Deal

## OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



*Bridging the gap between the manufacturer and your legacy test system.*

 1-800-915-6216

 [www.apexwaves.com](http://www.apexwaves.com)

 [sales@apexwaves.com](mailto:sales@apexwaves.com)

*All trademarks, brands, and brand names are the property of their respective owners.*

**Request a Quote**

 **CLICK HERE**

**BNC-2810**

# INSTALLING YOUR BNC-2810 SDA CONNECTOR BLOCK

This installation guide describes how to connect a BNC-2810 to your PCI/PXI-6810 serial data analyzer (SDA) and shows the BNC-2810 channel and signal connections.

## Introduction

---

The BNC-2810 is a connector block designed for use with a PCI/PXI-6810 serial data analyzer. You can use the BNC-2810 on a desktop or optionally mount it on a Deutsche Industrie Norme (DIN) rail that conforms to the Comité Européen de Normalisation Electrotechnique (CENELEC) 35 mm standard. The BNC-2810 provides easy access to the following channels and signals:

- RS-232 channels 0 and 1
- RS-485 channels 0 and 1
- Programmable channels 0, 1, and clock
- Input and output triggers
- Digital input/output (I/O) lines 0 through 7
- Output enable signals 0 and 1
- External power supply

Refer to *Getting Started with Your PCI/PXI-6810 Serial Data Analyzer* for more detailed information regarding these channels and signals.

# What You Need to Get Started

---

You need the following to set up and use your BNC-2810:


- Installing Your BNC-2810 SDA Connector Block* installation guide
- Your computer or PXI chassis
- One of the following devices:
  - PCI-6810 serial data analyzer
  - PXI-6810 serial data analyzer
- BNC-2810 SDA connector block
- SH6868-D1 shielded cable
- DIN rail mounting hardware (optional)

## Typical Connection

---

Figure 1 shows a typical connection of the BNC-2810 connector block to a PCI/PXI-6810 serial data analyzer. Use the following steps to install your BNC-2810:

1. Insert one end of the SH6868-D1 shielded cable into the 68-pin connector on your BNC-2810 connector block.
2. Insert the other end of the SH6868-D1 shielded cable into the 68-pin connector on your PCI/PXI-6810 serial data analyzer.




**Figure 1.** Typical BNC-2810 to PCI/PXI-6810 Connection

You can now connect to the channels and signals of your PCI/PXI-6810 serial data analyzer.

# Signal Connections

Figure 2 shows the BNC-2810 channel and signal connections.



**Figure 2.** BNC-2810 Signal Connections

Refer to your *Getting Started with the PCI/PXI-6810 Serial Data Analyzer* for signal connections to the 68-pin connector.

