

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

GPIB-1014P

Installing the GPIB-1014P and NI-488M Handler in Sun Workstations

April 1990 Edition

Part Number 370955A-01

**© Copyright 1989, 1990 National Instruments Corporation.
All Rights Reserved.**

**National Instruments Corporation
6504 Bridge Point Parkway
Austin, TX 78730-5039**

**(512) 794-0100
(800) IEEE-488
Fax: (512) 794-8411**

Limited Warranty

The GPIB-1014P is warranted against defects in materials and workmanship for a period of two years from the date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace equipment that proves to be defective during the warranty period. This warranty includes parts and labor.

The media on which you receive National Instruments software are warranted not to fail to execute programming instructions, due to defects in materials and workmanship, for a period of 90 days from date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace software media that do not execute programming instructions if National Instruments receives notice of such defects during the warranty period. National Instruments does not warrant that the operation of the software shall be uninterrupted or error free.

A Return Material Authorization (RMA) number must be obtained from the factory and clearly marked on the outside of the package before any equipment will be accepted for warranty work. National Instruments will pay the shipping costs of returning to the owner parts which are covered by warranty.

National Instruments believes that the information in this manual is accurate. The document has been carefully reviewed for technical accuracy. In the event that technical or typographical errors exist, National Instruments reserves the right to make changes to subsequent editions of this document without prior notice to holders of this edition. The reader should consult National Instruments if errors are suspected. In no event shall National Instruments be liable for any damages arising out of or related to this document or the information contained in it.

EXCEPT AS SPECIFIED HEREIN, NATIONAL INSTRUMENTS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND SPECIFICALLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CUSTOMER'S RIGHT TO RECOVER DAMAGES CAUSED BY FAULT OR NEGLIGENCE ON THE PART OF NATIONAL INSTRUMENTS SHALL BE LIMITED TO THE AMOUNT THEREFORE PAID BY THE CUSTOMER. NATIONAL INSTRUMENTS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF. This limitation of the liability of National Instruments will apply regardless of the form of action, whether in contract or tort, including negligence. Any action against National Instrument must be brought within one year after the cause of action accrues. National Instruments shall not be liable for any delay in performance due to causes beyond its reasonable control. The warranty provided herein does not cover damages, defects, malfunctions, or service failures caused by owner's failure to follow the National Instruments installation, operation, or maintenance instructions; owner's modification of the product; owner's abuse, misuse, or negligent acts; and power failure or surges, fire, flood, accident, actions of third parties, or other events outside reasonable control.

Copyright

Under the copyright laws, this book may not be copied, photocopied, reproduced, or translated, in whole or in part, without the prior written consent of National Instruments Corporation.

Trademarks

NI-488M™ are trademarks of National Instruments Corporation.

Product names listed are trademarks of their respective manufacturers. Company names listed are trademarks or trade names of their respective companies.

Contents

Section One

Introduction	1-1
What Your Kit Should Contain	1-1
Distribution Software	1-1
Related Documents	1-2

Section Two

Hardware and Software Installation	2-1
Considerations	2-1
Set Up a Working Directory	2-1
Install the GPIB Software	2-1
Automatic Installation	2-1
Manual Installation	2-1
Install the Utility Files	2-1
Install the C Library	2-2
Install the NI-488M Driver for SunOS 4.x	2-2
Turn the System Off	2-3
Configure and Install the Hardware	2-4
Verify the Software Installation	2-4
Configure the Software	2-5

Appendix

Troubleshooting	A-1
Hardware	A-1
Software	A-1

Section One

Introduction

This guide details the steps necessary to install National Instruments NI-488M SunOS software and the GPIB-1014P-1 interface board in Sun Workstations.

What Your Kit Should Contain

Your NI-488M Handler kit should contain the following items:

Item	Part Number
<i>Installing the GPIB-1014P and NI-488M Handler in Sun Workstations</i>	320170-01
<i>NI-488M Software Reference Manual</i>	320062-01
One of these software media:	
• Streaming tape for the NI-488M SunOS software	460130-14
• 9 track tape for the NI-488M SunOS software	430130-14

Make sure each of these items is in your kit. If any item is missing, contact National Instruments.

Distribution Software

The distribution medium is in tar format. The file structure of the distribution tape is shown below

SUN3s SUN4s install_gplib

Each Sun directory contains seven files, which are listed and described briefly below. An interactive program, `install_gplib`, will install the GPIB software automatically.

<code>gplibx.o</code>	NI-488M handler (where x refers to the type of Sun machine)
<code>cib.c</code>	C language library
<code>ugplib.h</code>	Include file for user programs
<code>ibtsta</code>	Installation test part A
<code>ibtstb</code>	Installation test part B
<code>ibic</code>	Interactive control utility
<code>ibconf</code>	Software configuration utility

Related Documents

This guide is to be used with the following manuals:

- National Instruments *GPIB-1014P User Manual*, Part Number 320026-01
- Sun System manuals for the SunOS 4.x operating systems

Section Two

Hardware and Software Installation

Considerations

This guide assumes that the user has super-user privileges (logged in as root) and that all the software needed for adding device drivers is already installed.

Set Up a Working Directory

1. Log on as super-user (root).
2. Create a working directory (for example, /usr/gpib) and change to that directory.
3. Extract the distribution files from the distribution medium using the tar command.

Install the GPIB Software

For easy, automatic installation of the software, run the install program. Otherwise, refer to the steps for manual installation.

Automatic Installation

Run the program `install_gpib`. The program will prompt you for the information it needs to install the GPIB software.

Manual Installation

Install the Utility Files

1. Copy the file `ugpib.h` to `/usr/include/sys/ugpib.h`.
2. If you have a Sun-3 machine, copy the file `gpib3.o` to `/sys/sun3/OBJ/gpib.o`.
If you have a Sun-4 machine, copy the file `gpib4.o` to `/sys/sun4/OBJ/gpib.o`.
3. Copy the files `ibic` and `ibconf` to a directory in the command search path (for example, `/bin` or `/usr/bin`).

Refer to subsequent steps for instructions on the remaining files.

Install the C Library

The file `cib.c` should be compiled and turned into a library as demonstrated in the following steps. This is necessary because the information in the *NI-488M Software Reference Manual* assumes that a library has already been created for the C language interface.

```
cc -c cib.c
ar r /lib/libgpib.a cib.o
ranlib /lib/libgpib.a
```

Alternately, `cib.o` can be added to an existing library or included during the link phase of each compile operation.

Install the NI-488M Driver for SunOS 4.x

The following steps build a new SunOS 4.x UNIX kernel with the NI-488M driver installed.

1. Change to `/sys/sun` directory and edit the file `conf.c`. Find the block of function definitions preceding the character device table `cdevsw` and add the following lines:

```
#include "ib.h"
#if NIB > 0
int ibopen(), ibclose(), ibread(), ibwrite(), ibioctl();
#else
#define ibopen      nodev
#define ibclose     nodev
#define ibread      nodev
#define ibwrite     nodev
#define ibioctl     nodev
#endif
```

The file `ib.h` is a file created automatically by the system in step 6. The file `ib.h` will contain the single line:

```
#define NIB x
```

where `x` is the number of GPIB boards configured in the UNIX kernel.

At the end of the character device table `cdevsw`, located in the file `conf.c`, add the following lines:

```
(  ibopen,      ibclose,      ibread,      ibwrite,      /*xx*/
   ibioctl,     nodev,        seltrue,     0,
   0,
),
```

Note: This table has the same structure as the character device table `cdevsw` in `/usr/include/sys/conf.h`.

Each device in the system has a major device number. To determine the major device number of the GPIB board, choose the number after the largest device number currently in your system. All GPIB boards and devices use the same device number. In this example, the major device number is `xx`, as shown in the comment `/*xx*/` previously.

2. Use the following command, replacing *xx* with your major device number from step 1, to create a special node for device *gpib0*:

```
mknod /dev/gpib0 c xx 255
```

3. If you have a Sun-3 machine, change to */sys/sun3/conf*. If you have a Sun-4 machine, change to */sys/sun4/conf*. Edit the file *files*. Add the line:

```
sundev/gpib.c optional ib device-driver
```

4. Create a configuration file named *GPIB* by copying an existing configuration. *GENERIC* is the default generic Sun configuration file. If you already have a local configuration different from *GENERIC*, copy it instead.

```
cp GENERIC GPIB
```

5. Edit the file *GPIB* and add the following line to the end of the file:

```
device ib0 at vme16d16 ? csr 0x2000 priority 2 vector ibintr 0xC8
```

This line indicates a GPIB controller is at VME address 0x2000, interrupt level 2, and interrupt vector 0xC8. The GPIB-1014P-1 uses addresses 0x2000 through 0x2010. If any of these addresses is already in use, select a different base address. For an additional GPIB controller, add another line similar to the one above. The device name would be *ib1*, the interrupt level can stay the same but the VME address and the interrupt vector would have to change.

6. Create the new system and be sure to save the old version of */vmunix* as shown below.

```
config GPIB
cd ../GPIB
make
cp /vmunix /vmunix.old
cp vmunix /vmunix
```

Turn the System Off

1. The new UNIX kernel, */vmunix*, is ready to be started. Halt the system:

```
halt
```

2. Shut down the system and turn the power off.

Configure and Install the Hardware

Refer to Section Three of the *GPIB-1014P User Manual* for the following steps.

1. Jumper the board to select the following configuration:
 - privileged access upon power up
 - the same base address as in the software configuration
 - interrupt request line IRQ2*
 - interrupt priority code for IRQ2*
 - Status/ID Byte of C8 (hex)
 - GPIB cable shield isolated
2. With the power off, remove the panel from the rear of the machine.
3. Plug the GPIB-1014P-1 into an empty slot. This slot should be higher than 6 (7 through 12) if the card cage has 12 slots.
4. Open the front hatch of the Sun and remove all jumpers for this slot.
5. Reattach the front and rear panels.

Verify the Software Installation

Restart the Sun computer. The following message should appear on the screen:

```
ib0 at vmel6d16 csr 0x2000 pri 2 vector 0xC8
```

If it does not appear, check that the GPIB-1014P-1 address jumper settings are the same as specified in step 5.

There are two software installation tests: `ibtsta` and `ibtstb`. `ibtsta` checks for a correct node `/dev/gpib0` and correct access to the device driver. `ibtstb` checks for correct Direct Memory Access (DMA) and interrupt operation. It requires a GPIB bus analyzer and can be omitted if an analyzer is not available.

Change to `/usr/gpib` and run `ibtsta` with the command:

```
ibtsta
```

If `ibtsta` completes with no errors, and a bus analyzer is available, run `ibtstb` with the command:

```
ibtstb
```

Configure the Software

Once the software is correctly installed, run the software configuration program `ibconf` (you must have super-user privileges). `ibconf` is a screen-oriented utility that you can use to inspect and modify default software parameters. In addition, it creates all the other device nodes needed by the software.

`ibconf` is largely self-explanatory; it has help screens to explain all commands and options. Run `ibconf` with the command:

```
ibconf /vmunix
```

where `/vmunix` can be any UNIX kernel with the NI-488M driver installed. Refer to the *NI-488M Software Reference Manual* for more details.

User Comment Form

National Instruments encourages you to comment on the documentation supplied with our products. This information helps us provide quality products to meet your needs.

Title: Installing the GPIB-1014P and NI-488M Handler in Sun Workstations

Edition Date April 1990

Part Number: 370955A-01

Please comment on the completeness, clarity, and organization of the manual.

If you find errors in the manual, please record the page numbers and describe the errors.

Thank you for your help.

Name

Title

Company

Address

Phone (

)

Mail to: Technical Publications
National Instruments Corporation
6504 Bridge Point Parkway, MS 53-02
Austin, TX 78730-5039