

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

NI-5761

Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

| Part Number and Revision | Description |
|--|--|
| 198812A-01L or later | NI 1483, CAMERA LINK ADAPTER MODULE |
| 151148A-0xL or later | NI 5731/5732/5733/5734, DIGITIZER ADAPTER MODULE |
| 153113A-0xL or later | NI 5741/5742, SIGNAL GENERATOR ADAPTER MODULE |
| 199543A-01L or later 158676A-01L or later | NI 5751/5751B, DC COUPLED DIGITIZER ADAPTER MODULE |
| 199468A-01L or later 158679A-01L or later | NI 5752/5752B, AC COUPLED DIGITIZER ADAPTER MODULE |
| 143234A-0x or later | NI 5753, DIGITIZER ADAPTER MODULE |
| 150937A-0x or later | NI 5761, DIGITIZER ADAPTER MODULE |
| 151727A-0xL or later | NI 5762, DIGITIZER ADAPTER MODULE |
| 195815A-0xL or later | NI 5771, DIGITIZER ADAPTER MODULE |
| 152125A-0xL or later | NI 5772, DIGITIZER ADAPTER MODULE |
| 196496A-01L or later | NI 5781, BASEBAND TRANSCEIVER ADAPTER MODULE |
| 153241A-0x or later | NI 5782, IF TRANSCEIVER ADAPTER MODULE |
| 158183A-0xL or later | NI 5783, BASEBAND TRANSCEIVER ADAPTER MODULE |
| 152888A-01L or later | NI 5791, RF TRANSCEIVER ADAPTER MODULE |
| 152889A-01L or later | NI 5792, RF RECEIVER ADAPTER MODULE |
| 152890A-01L or later | NI 5793, RF TRANSMITTER ADAPTER MODULE |
| 198713A-01L or later 156996A-01L or later | NI 6581/6581B, DIGITAL ADAPTER MODULE |
| 199490A-0xL or later | NI 6583, MIXED LOGIC DIGITAL ADAPTER MODULE |
| 199496A-0xL or later | NI 6584, RS-485/RS-422 DIGITAL ADAPTER MODULE |
| 190687A-01L or later 156999A-0xL or later | NI 6585/6585B, LVDS DIGITAL ADAPTER MODULE |
| 192169A-01L or later | NI 6587, LVDS DIGITAL ADAPTER MODULE |
| 157002A-01L or later | NI 6589, LVDS DIGITAL ADAPTER MODULE |

Volatile Memory

| Target Data | Type | Size | Battery Backup | User ¹ Accessible | System Accessible | Sanitization Procedure |
|-------------|------|------|----------------|------------------------------|-------------------|------------------------|
| None | | | | | | |

Non-Volatile Memory (incl. Media Storage)

| Target Data | Type | Size | Battery Backup | User Accessible | System Accessible | Sanitization Procedure |
|---|--------|------|----------------|-----------------|-------------------|------------------------|
| Device configuration, Product Identification and Configuration Data | EEPROM | 2 KB | No | Yes | Yes | Procedure 2 |

¹ Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible*

Procedures

Procedure 1 –Board Assembly Part Number Identification:

To determine the Board Assembly Part Number and Revision, refer to the label applied to the surface of your product. The Assembly Part Number should be formatted as “P/N: #####a-##L

Procedure 2 – Device Configuration EEPROM:

The Device Configuration EEPROM and its entire address space are exposed through the FlexRIO Host Interface in LabVIEW. To clear the entire EEPROM, overwrite the entire address space with null values using either the FlexRIO_Host_EEPROMWriteByteArray VI or FlexRIO_Host_EEPROMWrite32 VI.

Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per *NIST Special Publication 800-88 Revision 1*, “clearing” is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per *NIST Special Publication 800-88 Revision 1*, “sanitization” is a process to render access to “Target Data” on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.