COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

0

1-800-915-6216

www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



PXI-4465

support@ni.com



Board Assembly Part Number(s)

Part Number	Description
188261A-13L or later	PXI-4465

Manufacturer: National Instruments

Volatile Memory

		User Accessible/	Battery		
Type	Size	System Accessible ¹	Backup?	Purpose	Method of Clearing ²
RAM (FIFO in FPGA)	2047 bytes	Yes/Yes	No	Buffers data being read	Power Cycle

Non-Volatile Memory

Type ³	Size	User Accessible/ System Accessible	Battery Backup?	Purpose	Method of Clearing
MITE EEPROM	4 KB	No/No	No	PCI configuration	None available to user
Calibration EEPROM	4000 bits	Yes/No	No	User defined calibration	See clearing notes
Media Storage					
		User Accessible/	Battery		
Type	Size	System Accessible	Backup?	Purpose	Method of Clearing
NONE					

Clearing Notes:

EEPROM: User accessibility of the calibration EEPROM is exposed through an external calibration Applications Programming Interface (API) in LabVIEW. To declassify this memory, complete the following steps:

- 1. From the Functions palette, select **Measurement I/O»DAQmx Data Acquisition»Advanced»Calibration»Cal Info. node** and put the node on the block diagram.
- 2. Right-click the node and select **Change all to write**.
- 3. Expand the node to expose two items.
- 4. Left-click the items and select **ActiveDev** and then **Cal.UserDefinedInfo** from the menu.
- 5. Create a constant at the input of **ActiveDev**, then select your device from the drop-down menu.
- 6. Create a constant at the input of Cal.UserDefinedInfo, then enter " " in the box.
- 7. Run the VI

¹ Items are designated **No** for the following reason(s):

a) Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed.

b) Hardware-modifying software tools are not distributed to customers for any personal access or customization, also known as non-normal use.

² The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to clear the memory are not distributed by National Instruments to customers for normal use.

Calibration constants that are stored in device EEPROMs include information for the device's full operating range.
Calibration constants do not maintain any unique data for specific configurations at which the device is used unless otherwise specified.
EDITION DATE June 2016
Contact: 866-275-6964



Terms and Definitions

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

System Accessible Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

Cycle Power The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

Non-Volatile Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.

Contact: 866-275-6964 support@ni.com