COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

0

1-800-915-6216



www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



cRIO-9068



Board Assembly Part Number(s)

Part Number	Description
155195A-01L or later	cRIO-9068

Manufacturer: National Instruments

Volatile Memory

v diatife ivicii	noi y				
Type ¹	Size	User Accessible/ System Accessible ²	Battery Backup?	Purpose	Method of Clearing ³
DRAM	4Gb (2Gbx2	?) No/Yes	No	System Memory	Cycle power
FPGA w/	560KB	Yes/Yes	No	LabVIEW and User data	Cycle power
Block RAM					, 1
CPLD	32 bytes	No/Yes	No	CPLD Memory	Cycle power
RTC	20 bytes	No/Yes	Yes	Time Keeping	None available to user
Non-Volatile	Memory				
Type	Size	User Accessible/ System Accessible	Battery Backup?	Purpose	Method of Clearing
CPLD	.17MB	No/No	No	CPLD configuration	None available to user

No

No

No

-OS	No/Yes
-User Disk	Yes/Yes

1GB

No/No

User Accessible/	Battery		
System Accessible	Backup?	Purpose	Method of Clearing

Firmware

Operating System

User data

NONE

Type

Flash

-Firmware

Media Storage

Clearing Notes:

EEPROM: User accessibility of the calibration EEPROM is exposed through an external calibration Applications Programming Interface (API) in LabVIEW. To declassify this memory, complete the following steps:

1. Example info

None available to user

Format drive in MAX

Format drive in MAX

Calibration constants that are stored in device EEPROMs include information for the device's full operating range. Calibration constants do not maintain any unique data for specific configurations at which the device is used unless otherwise specified.

² Items are designated **No** for the following reason(s):

a) Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed.

b) Hardware-modifying software tools are not distributed to customers for any personal access or customization, also known as non-normal use.

³ The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to clear the memory are not distributed by National Instruments to customers for normal use.



Terms and Definitions

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

System Accessible Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

Cycle Power The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

Non-Volatile Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.

Contact: 866-275-6964 support@ni.com