

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

USB-8452


INSTALLATION GUIDE

USB-8452 Mounting Kit

This document explains how to attach the USB-8452 module to a wall or panel using the USB-8452 mounting kit. You can attach the module in either a removable or fixed configuration.

Removable Installation Instructions

Complete the following steps to attach the USB-8452 module in a removable configuration, which allows removing the module without detaching the mounting bracket from the wall or panel.




1. Attach the mounting bracket to a wall or panel using two #6 or M4 panhead screws (not provided). Refer to *Mounting Hole Spacing* above for recommended hole spacing dimensions.
2. Hook the USB-8452 module onto the mounting bracket by inserting the bracket hooks into the mating module slots (not visible in the figure above) and sliding the module downward.



Note To detach the USB-8452 module, slide the module upward and pull perpendicular to the mounting surface.

Fixed Installation Instructions

Complete the following steps to attach the USB-8452 module in a fixed configuration, which requires detaching the mounting bracket to remove the module from the wall or panel.



1. Attach the mounting bracket to the USB-8452 module by inserting the bracket hooks into the mating module slots. Slide the bracket upward to engage the bracket hooks temporarily.
2. Align the mounting bracket screw hole with the mating USB-8452 hole and use the provided #2 Phillips undercut flathead screw to attach the bracket to the module.
3. Mount the USB-8452 bracket assembly to a wall or panel using two #6 or M4 panhead screws (not provided). Refer to *Mounting Hole Spacing* on the previous page for recommended hole spacing dimensions.

LabVIEW, National Instruments, NI, ni.com, the National Instruments corporate logo, and the Eagle logo are trademarks of National Instruments Corporation. Refer to the *Trademark Information* at ni.com/trademarks for other National Instruments trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products/technology, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your media, or the *National Instruments Patent Notice* at ni.com/patents. You can find information about end-user license agreements (EULAs) and third-party legal notices in the USB-8452 Readme. Refer to the *Export Compliance Information* at ni.com/legal/export-compliance for the National Instruments global trade compliance policy and how to obtain relevant HTS codes, ECCNs, and other import/export data.