### **COMPREHENSIVE SERVICES**

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

## **SELL YOUR SURPLUS**

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

Sell For Cash Get Credit Receive a Trade-In Deal

# **OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP**

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



**Bridging the gap** between the manufacturer and your legacy test system.

0

1-800-915-6216



www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



NI-9247



**Board Assembly Part Number(s)** 

Part Number	Description
157225B-01L	NI 9247 3 CH CURRENT INPUT 50Arms

**Manufacturer:** National Instruments

**Volatile Memory** 

Size	User Accessible/ System Accessible <sup>1</sup>	Battery Backup?	Purpose	Method of Clearing <sup>2</sup>
24 bits x4	Yes/Yes	No	Stores last digitized value	Cycle power
6 bytes	Yes/Yes	No	Stores Module Configuration	Cycle power
Memory			,	
·	User Accessible/	Battery		
Size	System Accessible	Backup?	Purpose	Method of Clearing
1 KB	No/Yes	No	Module ID and calibration	None available to user
440 Macrocell	No/No	No	Module operation	None available to user
1 byte x3	No/No	No	Analog frontend compensation	None available to user
ge				
U	User Accessible/	Battery		
Size	System Accessible	Backup?	Purpose	Method of Clearing
	24 bits x4 6 bytes Memory Size  1 KB 440 Macrocell 1 byte x3	Size System Accessible  24 bits x4 Yes/Yes 6 bytes Yes/Yes Memory User Accessible/ Size System Accessible  1 KB No/Yes 440 Macrocell No/No 1 byte x3 No/No  ge User Accessible/	Size System Accessible Backup?  24 bits x4 Yes/Yes No 6 bytes Yes/Yes No  Memory  User Accessible/ Battery Size System Accessible Backup?  1 KB No/Yes No 440 Macrocell No/No No 1 byte x3 No/No No  ge  User Accessible/ Battery  Backup?	Size System Accessible¹ Backup? Purpose  24 bits x4 Yes/Yes No Stores last digitized value 6 bytes Yes/Yes No Stores Module Configuration  *Memory  User Accessible/ Battery  Size System Accessible Backup? Purpose  1 KB No/Yes No Module ID and calibration 440 Macrocell No/No No Module operation 1 byte x3 No/No No Analog frontend compensation  ge  User Accessible/ Battery

**NONE** 

## **Clearing Notes:**

**EEPROM:** User accessibility of the calibration EEPROM is exposed through an external calibration Applications Programming Interface (API) in LabVIEW. To declassify this memory, complete the steps listed in KB <u>4GHLANQE</u> (Clearing the User-Accessible EEPROM on an NI-DAQmx Supported Device)

May 2015 Contact: 866-275-6964 support@ni.com

Items are designated **No** for the following reason(s):

a) Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed.

b) Hardware-modifying software tools are not distributed to customers for any personal access or customization, also known as non-normal use.

The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to clear the memory are not distributed by National Instruments to customers for normal use.



### **Terms and Definitions**

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

**System Accessible** Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

**Cycle Power** The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

**Volatile Memory** Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

**Non-Volatile** Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.

May 2015 Contact: 866-275-6964 375244A-01 support@ni.com