COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock New, New Surplus, Refurbished, and Reconditioned NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

0

1-800-915-6216



www.apexwaves.com

sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote



PXI-5422

Contact: 866-275-6964

support@ni.com



Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
191946x-01(L)	MOD ASSY, NI PXI-5422, 200 MS/s, 16-bit, 8MB without LVDS
191946x-02(L)	MOD ASSY, NI PXI-5422, 200 MS/s, 16-bit, 32MB with LVDS
191946x-03(L)	MOD ASSY, NI PXI-5422, 200 MS/s, 16-bit, 256MB with LVDS
191946x-04(L)	MOD ASSY, NI PXI-5422, 200 MS/s, 16-bit, 512MB with LVDS

Volatile Memory

Target Data	Туре	Size	Battery Backup	User ¹ Accessible	System Accessible	Sanitization Procedure
Waveform Data	Synchronous DRAM	32 MB (-01, -02) 256 MB (-03) 512 MB (-04)	No	Yes	Yes	Cycle Power
Buffering Data	FPGA Block RAM	576 kbits	No	Yes	Yes	Cycle Power
Buffering Data	FPGA Block RAM	720 kbits	No	Yes	Yes	Cycle Power
Memory Control	FPGA Block RAM	14 KB	No	Yes	Yes	Cycle Power

Non-Volatile Memory (incl. Media Storage)

			Battery	User	System	Sanitization			
Target Data	Type	Size	Backup	Accessible	Accessible	Procedure			
Board Configuration	EEPROM	64 kbits	No	No	Yes	None			
Calibration information	EEPROM	16 kbits	No						
 Calibration metadata 				Yes	Yes	Procedure 2			
• Calibration constants ²				No	Yes	None			
FPGA Programming	CPLD	64	No	No	No	None			
MacroCells									

¹ Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible*

² Calibration constants that are stored on the device include information for the device's full operating range. Any implications resulting from partial self-calibration can be eliminated by running the full self-calibration procedure.

Contact: 866-275-6964

support@ni.com



Procedures

Procedure 1 – Board Assembly Part Number identification:

To determine the Board Assembly Part Number and Revision, refer to the label attached to U38. The serial number is printed on label attached to U33. Both U33 and U38 reference designators can be seen on the silk screen and are located on bottom side of module near the front panel.

Procedure 2 - Device Configuration EEPROM (Calibration Metadata):

The user-accessible areas of the Device Configuration Flash are exposed through a calibration Applications Programming Interface (API) in LabVIEW. To clear the calibration meta-data area, complete the following steps:

- 1. To clear the calibration password, from Labview use niFgen Change Ext Cal Password.vi to overwrite the password.
- **2.** To clear the user-defined information, from Labview use niFgen Set Cal User Devined Info.vi to overwrite user-defined information.

Contact: 866-275-6964

support@ni.com



Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per NIST Special Publication 800-88 Revision 1, "clearing" is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per NIST Special Publication 800-88 Revision 1, "sanitization" is a process to render access to "Target Data" on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.