

COMPREHENSIVE SERVICES

We offer competitive repair and calibration services, as well as easily accessible documentation and free downloadable resources.

SELL YOUR SURPLUS

We buy new, used, decommissioned, and surplus parts from every NI series. We work out the best solution to suit your individual needs.

 Sell For Cash  Get Credit  Receive a Trade-In Deal

OBSOLETE NI HARDWARE IN STOCK & READY TO SHIP

We stock **New**, **New Surplus**, **Refurbished**, and **Reconditioned** NI Hardware.



Bridging the gap between the manufacturer and your legacy test system.

 1-800-915-6216

 www.apexwaves.com

 sales@apexwaves.com

All trademarks, brands, and brand names are the property of their respective owners.

Request a Quote

 **CLICK HERE**

SB-MXI

Board Assembly Part Number(s)

Part Number	Description
180960E-01 or later	VME-MXI
181155-01 or later	SB-MXI

Manufacturer: National Instruments

Volatile Memory

Type ¹	Size	User Accessible/ System Accessible ²	Battery Backup?	Purpose	Method of Clearing ³
-------------------	------	--	--------------------	---------	---------------------------------

None

Non-Volatile Memory

Type	Size	User Accessible/ System Accessible	Battery Backup?	Purpose	Method of Clearing
------	------	---------------------------------------	--------------------	---------	--------------------

PROM	4536 bytes	Unknown	No	Configuration Data (VME)	Unknown
EEPROM	Unknown	Unknown	No	Configuration Data (VME)	Unknown
FPGA	2000 gates	Unknown	No	Unknown (VME)	Unknown
EEPROM	8 KB	Unknown	No	Unknown (SB)	Unknown
FPGA	4500 gates	Unknown	No	Unknown (SB)	Unknown
PROM	512 bytes	No/No	No	Unknown (SB)	N/A

Media Storage

Type	Size	User Accessible/ System Accessible	Battery Backup?	Purpose	Method of Clearing
------	------	---------------------------------------	--------------------	---------	--------------------

None

¹ Calibration constants that are stored in device EEPROMs include information for the device's full operating range and do not maintain any unique data for specific frequencies at which the device is used.

² Items above that are noted as **No** for User Accessible/System Accessible are for the following reason(s): Hardware changes or a unique software tool from National Instruments are required to modify contents of the memory listed. This software tool is not distributed to public users for any personal access or customization; also known as non-normal use.

³ The designation *None Available to User* indicates that the ability to clear this memory is not available to the user under normal operation. The utilities required to perform this action are not distributed by National Instruments to customers for normal use.

Terms and Definitions

User Accessible Allows the user to directly write or modify the contents of the memory during normal instrument operation.

System Accessible Does not allow the user to access or modify the memory during normal instrument operation. However, system accessible memory may be accessed or modified by background processes. This can be something that is not deliberate by the user and can be a background driver implementation, such as storing application information in RAM to increase speed of use.

Cycle Power The process of completely removing power from the device and its components. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory Requires power to maintain the stored information. When power is removed from this memory, its contents are lost.

Non-Volatile Retains its contents when power is removed. This type of memory typically contains calibration or chip configuration information, such as power up states.